



Project of the month.

May 2018.

A photograph of a modern, single-story house with a dark blue corrugated metal roof and light-colored walls. The house is situated on a grassy hillside under a clear blue sky. Two people are sitting on a wooden deck in front of the house. The foreground is filled with dry, brownish vegetation.

Te Horo Bach.

PARSONSON ARCHITECTS
PHOTOGRAPHY: PAUL MCCREDIE

The judges described Parsonson Architects' 87 square-metre bach in Te Horo as a "near-perfect" retreat from the city, with raw materials and charming interiors. "The exterior form and batten detailing set the home apart from the surrounding baches, yet the colours and materiality beautifully connect it with the landscape."

The bach also won a Resene colour award. "To subvert the limited colour palette available under subdivision rules, the architect has cleverly applied colours to the sides of exterior battens that are not evident when the façade is viewed straight on. Throughout the interior the colours applied are quirky, appropriate and plentiful."

INTERIOR



WOCA Diamond Oil is a fully penetrating product that leaves a natural and honest representation of timber. The benefits are also in what cannot be seen – the ingredients in Diamond Oil are derived from vegetable oil components, so it is eco-friendly and non-harmful for an everyday living or working environment. Diamond Oil is suitable for all interior timbers.

WOCA DIAMOND OIL NATURAL OKOUME PLYWOOD



- Based on vegetable oil components
- 100% penetrating oil, not film-forming
- No VOC
- 99% solid content
- Natural, sustainable and eco-friendly
- Ingredients independently certified by the German Biological Building Institute (IBR)
- Suitable for all interior timber surfaces

APPLICATION PROCESS

WOCA DIAMOND OIL



1. Apply WOCA Wood Cleaner, diluted 1:40 with water, to the clean, dry surface.
2. Apply Diamond Oil to the surface sparingly using a speed brush or roller. Allow the product to penetrate.
3. After 20 minutes, rub the oil into the wood with a cloth, nylon pad, or 360° gib tool.
4. Remove all excess from the surface with a clean cloth.
5. Dispose of cloths in a plastic bag containing water to avoid self-combustion.

The wood will be dry after 48 hours, and fully hard after 7 days.

Clean and maintain with WOCA Natural Soap, diluted 1:40.







PREPARE • TREAT • MAINTAIN

WOCA @ Design Denmark
12 Maidstone Street
Ponsonby, Auckland
09 361 3333

Darin Kitching
darin@woca.co.nz
021 978 754
woca.co.nz



wocanewzealand



wocanewzealand